

**IMPORTANT:
THESE INSTRUCTIONS ARE TO REMAIN
WITH THE HOMEOWNER**

These instructions are supplementary to the Installation and Operating Instructions supplied with the fireplace and should be kept together. Refer to the Installation and Operating Instructions for proper gas supply, safety requirements and operating instructions.



TOWN & COUNTRY
LUXURY FIREPLACES


**TC30
BLACK DIAMOND
BURNER KIT
INSTRUCTIONS**



**PART#
TC30.NG03C
For TC30 Series C**



Contents of Package



NOTE:

MUST BE USED WITH PORCELAIN PANEL SET PART# TC30.PNLPBKB

- A** MANIFOLD ASSEMBLY
(including supply tube)
- B** BURNER TUBE
- C** BURNER SHIELD
- D** MEDIA SPACER, Center
- E** MEDIA SPACER, Front
- F** MEDIA SPACER, Rear
- G** HARDWARE PACKAGE
- H** 5 lbs. GLASS MEDIA
- I** BURNER TRAY
- J** PILOT SHIELD
(including pilot and pilot supply tube)

Black Diamond Burner Installation


A porcelain panel set must be used in conjunction with the installation of the burner assembly. See Installation and Operating Instructions manual for details.

NOTE: Plug the 4 vacant holes in the bottom of the firebox with 1/2" screws, as they are not required to attach this style of burner.

NOTE: If unit is to be converted to Propane, see Propane conversion instructions on page 7 before proceeding.


1. Remove three screws from the rear of the firebox. Attach the manifold bracket to the rear of the firebox with the three screws previously removed. (Fig. #1)

Fig #1





2. Attach the manifold supply tube and the pilot supply tube to the bulk head fittings and tighten. (Fig. #2) Ensure that there are no leaks.


Fig #2



- Secure the electrical bulkhead plate and gasket to the firebox. (2 screws) Attach the ignition and sensor wires to the module. Red end to the connector marked by the red dot, white end to the connector marked by the white dot (Fig. #3 & 4)



4. Install burner shield by tipping the shield into the firebox. Route pilot up through the opening in the burner shield. (Fig. #5)



5. Attach the burner tray to the burner shield using two screws at the back of the tray. (Fig. #6)



6. Attach pilot shield to burner tray with two screws. (Fig. #7)

Fig #7



7. Front and rear media spacers are now installed. (Fig. #8 & 9)

Fig #8



Fig #9




8. Install burner by tilting burner inlet through tray. Ensure that the orifice has entered the inlet tube. (Fig#10).

Set the air shutter to fully open for Propane or fully closed for Natural gas.

Fig #10



9. Install the center media spacer and secure to the tray with two 1 1/2" screws.
(Fig. #11 & 12)
Three holes must line up to set each screw.



10. Apply just enough glass media to cover the burner assembly. (Fig #13 & 14)

NOTE: Too much glass media over the burner will cause sooting with the use of propane gas.

Fig #13



Fig #14



Propane Conversion

WARNING

This conversion kit shall be installed by a qualified service agency in accordance with the manufacturer's instructions and all applicable codes and requirements of the authority having jurisdiction.




If the information in these instructions is not followed exactly, a fire, explosion or production of carbon monoxide may result causing property damage, personal injury or loss of life.

The qualified service agency is responsible for the proper installation of this kit. The installation is not proper and complete until the operation of the converted appliance is checked as specified in the manufacturer's instructions supplied with the kit.

CAUTION

The gas supply and electrical power shall be shut off before proceeding with the conversion.


If the unit is to be used on propane convert as follows using the components supplied with this fireplace:

| | |
|---|--|
|  For use with model: TC30 Pour utiliser avec du modèle: Series C |  |
| | |
| LP GAS/ DU GAZ LP | |
| 12.5 in/wc / 12.5 po/c.e. (3.11 kPa) 13.9 in/wc / 13.9 po/c.e. (3.45 kPa) 11.0 in/wc / 11.0 po/c.e. (.95 kPa) | |
| # 48 (1.93 mm) | |
| Max.: 35,000 (10.3) Min.: 27,000 (7.91) | |
| This appliance was converted to PROPANE GAS with this kit on this date by the organization which accepts the responsibility that this conversion has been properly made. / Cet appareil était converti au gaz LP par l'emploi de la trousse de conversion par une organisation qui accepte la responsabilité pour une installation en bon état. | |
|  Intertek 5052.52085 | |

Note:


Factory supplied components must be used to ensure correct input. After conversion confirm proper manifold pressure.

1. Ensure the burner, pilot and gas supply are turned off, and the appliance has cooled.
2. Using a 1/2" wrench, undo the natural gas burner orifice, (marked #32). (Fig. #15)
3. Apply a small amount of pipe joint compound to the threads of the propane burner orifice (marked #48) to ensure a good seal, before screwing it into the fitting.
4. Open primary air shutter fully.
5. With a 7/16" wrench loosen the pilot head on the pilot assembly (Fig. #16)




- Slide the pilot adjustment band over and ensure that the hole in the orifice band is showing. (Fig. #17 indicates NG position, Fig. #18 indicates LP position)

Fig #17




- Remove access panel, 10 screws, and set aside. (Fig. #23)

Fig #18



8. Remove the minimum rate screw located in the valve. (Fig. #19)

Fig #19



9. Replace the minimum rate screw with the one provided in the propane conversion kit supplied with this burner. Ensure that the screw is fully installed. (Fig. #20)

The minimum rate screw is sealed with an o-ring. Use a thin bladed screwdriver to back the screw out to the limit of the threads.

A groove on the screw body will be visible just above the valve body. Insert a thin tool (knife blade or thin screwdriver blade) into the groove and gently pry the screw up.


It helps to rotate the screw while lifting on it.

Fig #20




- 10) Pull off the aluminum cap from the top of the pressure regulator. (Fig. #21)

Fig #21






- 11) Press down on the center post and rotate 90°. The center post should stay down. (Fig. #22). Replace the aluminum cap.

Fig #22




12) Fill in the date and the name of the person who performed the conversion in the white area on the conversion label. Peel off the protective backing and apply the conversion label directly over the gas specifications on the rating label.

| | | | | | | | | |
|---|---|---|------------------------------|--|--|---|--|----------------|
|  Intertek Date: <input type="text"/> By / Par: <input type="text"/> | For use with model: TC30 Pour utilise avec du modèle: Series C |  | | | | | | |
| | <table border="1"> <tr> <td style="text-align: center;">LP GAS/ DU GAZ LP</td> <td rowspan="5" style="vertical-align: top;"> This appliance was converted to PROPANE GAS with this kit on this date by the organization which accepts the responsibility that this conversion has been properly made. / Cet appareil etair convertir au gaz LP par l'emploi de la trousse de conversion par une organization qui accepte la responsabilité pour une installation en bon état. </td> </tr> <tr> <td style="text-align: center;">12.5 in/wc /12.5 po/c.e. (3.11 kPa)</td> </tr> <tr> <td style="text-align: center;">13.9 in/wc / 13.9 po/c.e. (3.45 kPa)</td> </tr> <tr> <td style="text-align: center;">11.0 in/wc / 11.0 po/c.e. (.95 kPa)</td> </tr> <tr> <td style="text-align: center;"># 48 (1.93 mm)</td> </tr> <tr> <td style="text-align: center;">Max.: 35,000 (10.3) Min.: 27,000 (7.91)</td> <td></td> </tr> </table> | | LP GAS/ DU GAZ LP | This appliance was converted to PROPANE GAS with this kit on this date by the organization which accepts the responsibility that this conversion has been properly made. / Cet appareil etair convertir au gaz LP par l'emploi de la trousse de conversion par une organization qui accepte la responsabilité pour une installation en bon état. | 12.5 in/wc /12.5 po/c.e. (3.11 kPa) | 13.9 in/wc / 13.9 po/c.e. (3.45 kPa) | 11.0 in/wc / 11.0 po/c.e. (.95 kPa) | # 48 (1.93 mm) |
| LP GAS/ DU GAZ LP | This appliance was converted to PROPANE GAS with this kit on this date by the organization which accepts the responsibility that this conversion has been properly made. / Cet appareil etair convertir au gaz LP par l'emploi de la trousse de conversion par une organization qui accepte la responsabilité pour une installation en bon état. | | | | | | | |
| 12.5 in/wc /12.5 po/c.e. (3.11 kPa) | | | | | | | | |
| 13.9 in/wc / 13.9 po/c.e. (3.45 kPa) | | | | | | | | |
| 11.0 in/wc / 11.0 po/c.e. (.95 kPa) | | | | | | | | |
| # 48 (1.93 mm) | | | | | | | | |
| Max.: 35,000 (10.3) Min.: 27,000 (7.91) | | | | | | | | |
|  Intertek 080411 6-TC30 5052.52085 | | | | | | | | |

13) Attach the access panel to the side of the firebox with the previously removed screws. (Fig. #23)

Note: Gasket must be installed with access panel.

Fig #23



Gas Pressure Check

Note: To test the gas pressure, turn off the gas supply before removing the plug from the supply pressure test port or manifold pressure test port.

Verify gas pressures with the fireplace lit and on the highest setting.

Fig #25a




Fig #24



1. Remove the plug from the pressure test port. The plug is located between the right side lintel and firebox side. (Fig. #24)

Fig #25



2. Thread the extension test fitting into the open test port. (Fig. #25)
3. Attach a pressure gauge onto the fitting.
4. When testing is complete remove the extension test fitting and replace the plug. Thread sealant will be required to ensure a gas tight connection.

Correct gas pressure requirement:

| Supply Pressure | Natural Gas | Propane |
|---|-------------|----------|
| Min. Pressure (For purpose of input adjustment) | 5.0" WC | 12.5" WC |
| Max. Pressure | 13.9" WC | 13.9" WC |
| Manifold Pressure | | |
| Maximum | 3.8" WC | 11" WC |
| Minimum | 2.1" WC | 5.5" WC |

Burner Flame Adjustment

The air shutter on the burner tube controls the primary combustion air to the gas burner and is preset at the factory for natural gas fuel. Some adjustment may be necessary to obtain desired flame and to eliminate carbon deposits. Evaluate flame appearance after the fireplace has reached operating temperature. See Fig. #28 for proper flame pattern.

Open primary air shutter if the glass media, glass, and firebox have carbon accumulation and/or the flames are long, dark and stringy. The shutter may also be opened to lessen the flame height.

The flame should be just orange and “lazy”.

It should **NEVER** be set to create sooting on internal parts and window glass.

Fig #28




Replacement Parts

(WHEN ORDERING, INCLUDE PART NUMBER WITH DESCRIPTION)

| ITEM | DESCRIPTION | PART NO. |
|------------|-------------------------------------|---------------|
| #1..... | TC30 BLACK DIAMOND BURNER KIT | TC30.NG03C2 |
| #2..... | BURNER TUBE | TC36. 5011835 |
| #3..... | PILOT ASSEMBLY, CONVERTIBLE | TCRP.5005025 |
| #4..... | PILOT SUPPLY TUBE | 5019.225 |
| #5..... | ORIFICE, NG (#32)..... | 5021.332A |
| #6..... | MANIFOLD SUPPLY TUBE..... | 5019.223 |
| #7..... | GLASS MEDIA | 5012.01 |
| * #8..... | PROPANE CONVERSION KIT..... | TC30.LPCE01 |

* NOT SHOWN





TOWN & COUNTRY
L U X U R Y F I R E P L A C E S

Technical support: 1-250-748-1184
Web site: www.townandcountryfireplaces.net
2975 Allenby Rd., Duncan, BC V9L 6V8